


# how to measure for hinge holes

1. Measure from the top of the door to the centre of the top hole.
2. Measure from the bottom of the door to the centre of the lower hole.



**Note:** The unit will be taller than the door, therefore the measurements need to be to the top/bottom of the door rather than the top/bottom of the unit.

For help or if you have any questions please call

0800 246 5954

or email [sales@rstkitchens.co.uk](mailto:sales@rstkitchens.co.uk)

 **first kitchens**  
Replacement Kitchen Doors